



FISCO 400



FISCO 400



HOW TO PLAY

- One, two, three, or four player driving game. Up to four players in four different colored cars can race with each other, while any unselected cars are computer driven.
- Player may choose one of three different tracks to begin the race, then as the game progresses slight alterations to the course will appear automatically.
- Animated starter with flag appears on the starting line and when the flag turns green the game begins.
- As player successfully drives around the course his score is displayed in the same color emeralds as his car. The score of the player who has the most points will be flashing on and off.
- Game time is indicated by the seven segment multi-colored band displayed in the middle of the screen. As time elapses one segment at a time will disappear and when the last segment has disappeared the game is over.

FEATURES

- Solid state circuitry for dependable trouble free operation.
- Big 22" color monitor, changing tracks, realistic sound effects make this a must for every location.

SPECIFICATIONS

Height	75 inches (1,900 mm)
width	30 inches (770 mm)
Depth	47 inches (1,200 mm)
Weight	255 lbs (130 kgl)
Power	280 W



Manufactured by

TAITO CORPORATION

Mailing address: Central P.O. Box 1164,
Tokyo, Japan

Cable Address: EPTRA TOKYO

Telex: J 22931 Tokyo

Printed in Japan